The Pico has 4 ADC Channels.

ADC0, ADC1, and ADC2 can be connected with GP26, GP27 & GP28 pins respectively

ADC4 is connected to its internal temperature sensor.

To test your MH Photoresistor sensor, connect it to the Pico as follows:

VCC to 3.3V

GND to any of the Ground Pins


AO to Pin(26)

The following code will give you the readings from the photoresistor

from machine import ADC ,Pin import time lightsensor = ADC(Pin(26))

while True:

light = lightsensor.read_u16()
print(light)
time.sleep(.1)



Vary the light falling on the photoresistor

and see the light value changes.

You can also see the graphical representation of the light values in a plotter by turning Thonny's plotter on.

Go to View, And check Plotter as shown in the image.

